

SECRET

6 JAN 71 14 09

OUT - 71525

S E C R E T #61382Z JAN 71 CITE [REDACTED] 0128

25X1

25X1

CORONA

FROM [REDACTED]

25X1

1. PERFORM THE FOLLOWING MODIFICATION TO DISC TAKE-UP S/N 19 TO ELIMINATE THE SHORTING CONDITION THAT EXISTS BETWEEN THE DISC TAKE-UP UNREG. RETURN AND CASE (SKIN) GROUND.

DISABLE 1 REV ROTATION POTS R315 AND R318 BY REMOVING PINS

J139-C

J139-D

J139-E

J139-F

J139-M

FROM CONNECTOR J139.

2. THE ROTATION MONITORS ARE A NON-FLIGHT ITEM AND ARE USED TO MONITOR ROTATION DURING TEST ONLY. MEASUREMENT OF SPOOL RPM AFTER FINAL T/U INSTALLATION WILL BE PERFORMED BY COUNTING SPOOL ROTATION USING A STOP WATCH.

3. HOLD T/U'S FOR REMAINING MISSIONS AT [REDACTED] UNTIL TEST AND SCHEDULE PLANS ARE COMPLETE.

25X1

S E C R E T

END OF MESSAGE

GP-1

DISTRIBUTION		
CY	OFFICE	PI
1	PIRE	
2	CABLE SEC.	
	PIRE/OD	
	SECUR.	
3	TEDE	APSD
	PSC/CC	
	AND	
	MEMRO	
	AND	
	IBG	
	IBG/OD	
	COMEN	
	IBG	
	IBG	
	IBG/END	
	IBG	
	DIA-EX4	
	SPED	
	DIA-AP	
	[REDACTED]	25X1
	CMX	

SECRET

ADVANCE CY

25X1